

'Piranha Off Road products are not associated in any way with FORD Motor Co of Aust Ltd or any of its related companies'

To Suit FORD TERRITORY MULTI POINT FUEL INJECTED (EARLY)



PART NUMBER
BTFT06
APPROX FITTING TIME
2 Hours
MAX BATTERY SIZE
OPTIMA D34
RECOMMENDED TYPE
Cycle Duty
TRAY LOCATION
DSFT



PARTS INCLUDED WITH TRAY

- 1 M6 Countersunk
- 3 X M6 Countersunk Long
- 4 X M6 Nuts
- 1 X M6 Hex
- 2 X J Bolts
- 1 X Special Top Mount
- 1 X M6 Rivnut

RECOMMENDED ISOLATOR

**DBE140SF
or
DBE180-SX**

FITTING INSTRUCTIONS

The cradle fits drivers side front.

1. Remove original battery box. Remove bracket holding power steering pipe.
2. Move overflow reservoir out of the way
3. Remove fuse box & slot top holes 10mm towards front of car, champher underneath of top mounting holes to fit inner guard and trim front leg to suit
4. Space up tray with 15mm marine ply to level out tray. Dent inner guard to stop battery fouling on guard.
5. Bolt in new dual tray (3xM6 Long counter sunk to be trimmed down to suit)
6. Reshape power steering pipe to avoid contact with tray
7. Fit batteries and place top mount in place. Mark hole for rivnut in inner guard and secure top mount
8. Replace overflow hose with new length of hose and remount overflow bottle in original position
9. Check clearance of hoses and pipes on tray and adjust if necessary and cable tie hoses to top mount

Ensure, Before closing the bonnet that all items fitted have adequate clearance