

# PIRANHA OFFROAD PRODUCTS

BTMFRU

'Piranha Off Road products are not associated in any way with MAZDA Australia Pty Ltd or any of its related companies'  
 'Piranha Off Road products are not associated in any way with FORD Motor Company Australia Pty Ltd or any of its related companies'

To Suit PX FORD RANGER / MAZDA BT50  
 2013



NOT SUITABLE FOR BELT FIT

PART NUMBER	BTMFRU
APPROX FITTING TIME	2 Hours
MAX BATTERY SIZE	Optima D31A
RECOMMENDED TYPE	Optima D31A
TRAY LOCATION	UNDERBODY



Fig 1

<b>PARTS INCLUDED WITH TRAY</b>
1 x Hold Down Top Mount 1 x M8 Bolt 1 x Spring Washer 2 x Chassis Plates 4 x Chassis Bolts M12 4 x Nyloc Nuts M12 4 X Washers
<b>RECOMMENDED ISOLATOR</b>
<b>DBE140S / DBE180-SX</b> Ford- Have dealer turn Off "Smart Charge Feature"

1. Remove 4 bolts holding transfer box guard and remove guard
2. Position tray as close as possible to fuel tank guard and using M12 bolts and nyloc nuts and washers secure tray to chassis rail. Check clearance of fuel lines and brake lines, shroud lines with split tube(not supplied) where they pass over top bracket.
3. Install battery and ensure clearance to fuel tank and secure battery.